



**The Wyeth-Scott Company**

ESTABLISHED 1906

**MANUFACTURER OF THE MORE POWER PULLER®**

85 Dayton Road • P.O. Box 888 • Newark, OH 43058-0888 • USA  
Phone: 800/743-4521 or 740/345-4528 • Fax: 740/345-0123  
www.wyeth-scott.com • Email: sales@wyeth-scott.com

## Instructions to Attach Cable to Reel & Install End Hook (H1) with Cable Clamps

Check out our video of this process on YouTube

Please feel free to call with any questions:  
800/743-4521 or 740/345-4528

Best time to call for technical assistance is Monday thru Friday 8:30 to 4:00 ET

**READ ALL DIRECTIONS BEFORE STARTING**

### **PARTS NEEDED:**

- Part # P620, P630 or P635 - Cable in 20', 30' or 35' lengths  
The RF (rivet & ferrule) is already installed on cable by WS. This attaches the cable to the reel
- Part # P13 - 5/16" Cable Clamp - 2 Required - Reattach H1 end hook to cable

### **P620 with RF attached by WS**



### **RF Close-up**



## TOOLS / ITEMS NEEDED:

- Common Sense...
- Safety Glasses
- Gloves
- Ball Peen Hammer
- Tapered Punch - 7/16"
- Bolt 5/8" x 2" Long with Nut
- (2) Wrenches for Bolt/Nut - 7/8"
- Heavy Metal Table/Surface
- Wrench – 1/2"

*Note: There are many different ways this could be done. One example is:*

- *Instead of peening rivet in reel with a punch & hammer*
  - > *Use a pneumatic (air) chisel with a blunt chisel*


### Tools / Items



## INSTALLATION OF CABLE/RF TO REEL

- Put puller on its side with the W10 frame hook facing left.
- Make sure the RF hole in reel is accessible (on top).
- From the bottom of the puller, on the side closest to the frame hook, bring the RF to the top inside of the reel.
- With the long part of cable in the RF on top, put rivet through hole on the inside of reel.

**RF ready to be put thru top hole**




**Unpeened rivet**



- Insert bolt between the RF and the other side of the reel.  
Tighten bolt with two 7/8" wrenches.
- Move to a very sturdy metal table or surface.  
If table/surface is not sturdy enough, bolt will come out during peening.
- On the outside of the reel, with a 7/16" punch and ball peen hammer, peen the shank of rivet to the reel.

**Bolt installed**



**Peen RF's rivet down with punch & ball peen hammer**



- After rivet is peened down, remove bolt.

**Rivet is peened down**



- Put blank end of cable thru frame hole.
- **IF** you have an older style non-removable P15 tackle block hook, put it over the blank end of the cable now.

## **INSTALLATION OF 5/16" CABLE CLAMPS**

- Put 2 cable clamps over blank end of cable.
- Put your end hook (#H1) over blank end of cable.
- Put cable clamp U bolts over the short end of cable. It is VERY IMPORTANT to install clamps this way. See picture below.
- Tightened clamps with ½" wrench. Tighten them "tight".

**Cable clamps installed**



---

➤ **THESE INSTRUCTIONS ARE ONLY MEANT TO BE A BASIC GUIDE. THE WYETH-SCOTT CO. SHALL BE HELD HARMLESS FOR INJURIES RESULTING FROM IMPROPER REPAIR OF THE PULLER.** ⚡