

The More Power Puller®

Mfg. by The Wyeth-Scott Co. • Newark, Ohio • Phone: 800/743-4521 or 740/345-4528 • Email: sales@wyeth-scott.com

Instructions to Remove Cable and Attach Cable to Reel

Parts Needed:

- Part P620, P630 or P635 - Cable in 20', 30' or 35' lengths - RF is already installed on cable.
- **Optional** - If reattaching own cable &/or hook is not installed on cable
 - RF - Rivet and Ferrule - Attaches cable to reel
 - P13 - 5/16" Cable Clamp - 2 Required - Reattach H1 end hook to cable

Tools Needed:

- Safety glasses, gloves, etc. and common sense...
- Electric Hand Grinder
- Hammer
- Tapered Drive Pin (Punch) - Approximately 1/4" in diameter x 8" long
- Tapered Drive Pin (Punch) - Approximately 7/16" in
- Chisel

Removal of Cable from Reel:

- Read all directions before beginning.
- Pull cable all the way out of the puller.
- Remember the hole the rivet is in and how the RF is placed
- With a hand grinder, grind off the outside edge of the rivet that goes through the cable and reel.
- With a 1/4" punch and hammer remove that rivet from the reel
- Cut the cable with a chisel close to the RF
- Remove cable from puller.

Installation of RF/Cable to Reel

- Put puller on its side with the W10 frame hook facing left.
- Make sure the RF hole in reel is accessible (on top).
- From the bottom of the puller, on the side closest to the frame hook, bring the RF to the top inside of the reel.
- With the long part of cable in the RF on top, put rivet through hole on the inside of reel.
- On the outside of the reel, with a 7/16" punch and hammer, peen the shank of rivet to the reel. Be sure to support the head of rivet on steel.
- **Always keep at least "3 wraps" of cable around reel at all times.**