

The More Power Puller®

Mfg. by The Wyeth-Scott Co. • Newark, Ohio • Phone: 800/743-4521 or 740/345-4528 • Email: sales@wyeth-scott.com

Instructions to Remove Reel (R17C)

Tools Needed To Remove R17 Reel:

- Safety glasses, etc. and common sense...
- Electric Hand Grinder
- Hammer
- Drive Pin (Punch) - Approximately 13/16" in diameter x 8" long
- Blocking to elevate puller

Removal:

- Read all directions before beginning.
- Place the puller on it's side on a solid flat surface (workbench, etc.). Remember the direction the reel (teeth) are facing and the placement of the drag spring.
- Use an electric hand grinder to grind the flare end off the P8 flush with the frame.
- Turn puller on it's other side and repeat the above step.
- Elevate the puller approximately 6 inches from the workbench with one side facing up - at an angle. (Need room for the P8 to exit the puller frame)
- Place a drive pin (punch) over the P8 and drive the P8 out of the frame and the reel by hitting the drive pin (punch) with a hammer.
- After removing the P8, inspect the hole in the frame and reel that the P8 came out of for excessive wear. (Example: egg shaped or oversized) Excessive wear may cause the puller to be unsafe and not operate properly.